Outdoor Stainless Steel Stove Holder Instruction Manual

1. Product Introduction

This outdoor stainless steel stove holder is a lightweight, compact, and portable rack designed for outdoor scenarios such as BBQ, picnics, camping, and hiking. Made of high-quality stainless steel, it features strong load-bearing capacity, corrosion resistance, and durable performance, which can effectively support various types of stoves (such as gas stoves, charcoal stoves, and small electric stoves) and meet your outdoor cooking needs. With its strong compatibility and easy-to-carry design, it is an essential accessory for outdoor activities.

2. Product Features

- **Lightweight & Compact**: Adopts a foldable or detachable design (depending on the specific model), which is easy to store and carry. It takes up little space in your backpack or car trunk, making it ideal for outdoor travel.
- **High-Quality Material**: Made of food-grade stainless steel, non-toxic, harmless, high-temperature resistant, corrosion-resistant, and not easy to deform or rust, ensuring long-term use in outdoor environments.
- **Strong Load-Bearing & Stability**: The sturdy structure and thickened material enable the rack to bear a certain weight of stoves and cookware, with good stability to prevent tipping during use.
- **Strong Compatibility**: Suitable for most small and medium-sized outdoor stoves, including gas stoves, charcoal stoves, alcohol stoves, etc. It can also be used as a small storage rack for placing condiments, cookware, etc., with multiple uses.
- **Easy to Assemble & Disassemble**: No complicated tools are required. You can quickly assemble or disassemble the rack in a few minutes, saving time and effort.

3. Technical Parameters

Item	Specification
Material	Stainless Steel

Weight	Approx. 0.8-1.2kg (depending on model)
Unfolded Size	Approx. 30x30x25cm (LxWxH, depending on model)
Folded Size	Approx. 30x10x5cm (LxWxH, depending on model)
Load-Bearing Capacity	Max. 10-15kg (depending on model)
Applicable Scenarios	Outdoor BBQ, picnics, camping, hiking, fishing, etc.

4. Installation Instructions

1. Check the package contents: 1 x stainless steel stove holder (including all components such as brackets, crossbars, and fasteners), 1 x instruction manual.
2. Unfold the main bracket: Take out the stove holder and gently unfold the four supporting legs until they are fully extended and locked in place. Ensure that the legs are firmly fixed and not loose.
3. Install the crossbars: Align the crossbars with the reserved holes on the supporting legs, insert them firmly, and tighten the fasteners (if any) to ensure the crossbars are stable and not easy to fall off.
4. Check the stability: After installation, place the stove holder on a flat and solid ground, gently shake it to confirm that it is stable and not easy to tip. If it is unstable, adjust the height of the legs (if adjustable) or move it to a flatter surface.

5. Usage Instructions

1. Place the installed stove holder on a flat, dry, and non-flammable surface (such as stone, concrete, or a fireproof mat). Do not place it on grass, leaves, or other flammable materials to avoid fire hazards.
2. Put the outdoor stove on the center of the rack, ensuring that the stove is stable and does not exceed the load-bearing capacity of the rack. Do not place the stove at the edge of the rack to prevent tipping.

3. During use, avoid touching the high-temperature parts of the stove and the rack to prevent burns. Keep children and pets away from the stove and the rack to ensure safety.
4. After use, turn off the stove and wait for it to cool down completely before moving or disassembling the rack. Do not touch the rack when it is still hot.
5. When not in use, disassemble the rack or fold it according to the reverse order of installation, clean it, and store it in a dry and ventilated place to avoid rust.

6. Safety Precautions

- Do not exceed the maximum load-bearing capacity of the rack. Overloading may cause the rack to deform, break, or tip over, resulting in accidents.
- Use the rack in a well-ventilated outdoor environment. Do not use it in enclosed spaces (such as tents) to avoid gas leakage or carbon monoxide poisoning (when using gas or charcoal stoves).
- Keep the rack away from flammable and explosive materials (such as gasoline, alcohol, and fireworks) to prevent fire or explosion.
- Do not use the rack in severe weather (such as strong winds, heavy rain, or thunderstorms) to avoid instability or safety hazards.
- Children should use the rack under the supervision of adults. Do not let children assemble, disassemble, or use the rack alone.
- If the rack is damaged (such as deformation, rust, or loose parts), stop using it immediately to avoid accidents. Contact the after-sales service for repair or replacement.

7. Maintenance & Care

- After each use, wait for the rack to cool down, then wipe it with a damp cloth to remove oil stains, food residues, and dust. Dry it with a dry cloth to prevent rust.
- If there is rust on the surface of the rack, use a stainless steel cleaner to wipe it off, then dry it and apply a thin layer of edible oil (optional) to prevent further rusting.
- Store the rack in a dry, ventilated, and cool place. Avoid storing it in a humid or corrosive environment (such as near seawater) to extend its service life.
- Regularly check the fasteners and connecting parts of the rack. If they are loose, tighten them in time. If they are damaged, replace them with the same specifications.

8. After-Sales Service

If you encounter any problems during installation, use, or maintenance, please contact our customer service team. We will provide you with professional solutions within 24 hours.

Customer Service Email: support@example.com

Customer Service Hotline: +1-XXX-XXXX-XXXX

Warranty Period: 12 months from the date of purchase. During the warranty period, we will provide free repair or replacement for non-human damage.

Note: This manual is for reference only. The actual product may vary slightly due to different models. Please refer to the actual product for details.

© 2026 All Rights Reserved.

（注：文档部分内容可能由 AI 生成）